

Quad(4) port BRI OEM card

Thank you for purchasing the Quad(4) port BRI card.

Please go to <http://quadbri.pbxhardware.com/driver/> to locate the working drivers for the card. This card will work with the original bristuff drivers from <http://junghanns.net> (the LEDs do not work with the original drivers unless you apply the patch or use our driver tarball) as well as with misdn / chan_misdn.

Here are the example steps to install the card:

1) download the suitable driver from:

<http://quadbri.pbxhardware.com/driver/>

2) download the packages and compile the driver

```
cd /usr/src/
```

```
wget http://quadbri.pbxhardware.com/driver/bristuff-0.2.0-RC8s.tar.gz
```

```
tar xvfzp bristuff-0.2.0-RC8s.tar.gz
```

```
cd bristuff-0.2.0-RC8s
```

```
./install.sh
```

3) if you don't have any asterisk configuration files in /etc/asterisk then install the sample ones

```
cd asterisk-1.0.10
```

```
make samples
```

```
cd ..
```

4) configure the /etc/zaptel.conf according to your needs; or use the stock qozap/zaptel.conf configuration file:

```
cp qozap/zaptel.conf /etc/zaptel.conf
```

5) configure /etc/asterisk/zapata.conf or use the stock qozap/zapata.conf configuration file:

```
cp qozap/zapata.conf /etc/asterisk/zapata.conf
```

6) load the driver for Quad(4) port BRI card

```
modprobe qozap
```

```
ztcfg
```

7) If you have any more questions please email support@pbxhardware.com